

Lancair		
	<b>PREPARATION</b>	<b>CRUISE</b>
	Essence et inspection	Max : 2400 RPM - 22-23 Inches
	Fuel Selector Valve = SET 	
	Battery = ON <input type="checkbox"/>	<b>APPROACH</b>
		Downwing - 110kts, 12-15 Inches
	<b>START</b>	Gear = DOWN
	Fuel Pump = ON <input type="checkbox"/>	Flaps = 1/4-2/4
	Throttle 1/4	Base = 100kts, Flaps 3/4
	Magneto = START <input type="checkbox"/>	Final = 90kts, Flaps 4/4
	Fuel Pump OFF <input type="checkbox"/>	Fuel Pump = ON <input type="checkbox"/>
	Alternator = ON <input type="checkbox"/>	
	Avionics = ON <input type="checkbox"/>	<b>AFTER LANDING</b>
	BARO - Heading Bug	Flaps Up
		Fuel Pump = OFF <input type="checkbox"/>
	<b>TAXI</b>	
	RUNUP : 1500 RPM	<b>SHUTDOWN</b>
	Trim = SET 33%	Trim = Neutral
		Avionics = OFF <input type="checkbox"/>
	<b>TAKEOFF</b>	Light = OFF <input type="checkbox"/>
	Fuel Pump = ON <input type="checkbox"/>	Mixture = CUTOFF
	Rotate = 110kts	Magneto = OFF <input type="checkbox"/>
	Gear = Up	Alternator = OFF <input type="checkbox"/>
	Climb = 135kts 24-27 Inches, RPM as required	Battery = OFF <input type="checkbox"/>
	Fuel Pump = OFF <input type="checkbox"/>	Fuel Selector Valve = CLOSE 